



Note: Circled end of R6 & R8 get unsoldered and pulled out of PCB. The pulled out end gets directly connected to pin 2 of the related switch.

R6 goes only to Pin 2 of SW1  
 Pin 3 of SW1 connects to the vacant hole  
 PCB

R8 goes only to Pin 2 of SW2  
 Pin 3 of SW2 connects to the vacant hole  
 PCB