

## Screen Displays for Working with Protocol

### Turn on Screen

Setup=0 Freq Rds=1

F1=34922.00 D1=0.20

F2=00007.83 D2=0.50

Step 1

### Memory Group 33

Setup=0 Freq Rds=33

F1=34922.00 D1=0.20

F2=00007.83 D2=0.50

Step 1

### Modified Group 33

Setup=0 Freq Rds=33

F1=28000.00 D1=0.20

F2=00007.83 D2=0.50

Step 2

### Memory Group 34

Setup=0 Freq Rds=34

F1=34922.00 D1=0.20

F2=00396.83 D2=0.50

Step 3

### Modified Group 34

Setup=0 Freq Rds=34

F1=28000.00 D1=0.20

F2=00396.00 D2=0.50

Step 3

### **Changing Modes**

Setup=2      Modes=1  
1=SIMPLE, 2=PROTOCOL  
3=SWEEP

Step 4

### **Changing Modes**

Setup=2      Modes=2  
1=SIMPLE, 2=PROTOCOL  
3=SWEEP

Step 4

### **Selecting Protocol**

Setup=3      Protocol  
Range Starting = 17  
Range Stopping = 28

Step 5

### **Selecting Protocol**

Setup=3      Protocol  
Range Starting = 33  
Range Stopping = 34

Step 5

### **Timing Setup**

Setup=5  
Freq Time = 005  
Progm Time = 0001

Step 6 and Step 7

**With Setup=0 press rotary dial to run the Protocol**